




❶ X1



❷ X1



❸ X4




❹ X4





❺ X1


For **INTEL** Platform




❶ Insert 4 white bolt into the corresponding 775/115x slot on the bracket




❷ Put the white bolt into the hole and press down to hear the sound of the slot embedded.




❸ Install black intel pushpin and press it down to the bottom.



❹ Apply the heat-conducting paste evenly on the CPU.




❺ Fasten the hook on both sides of the radiator to the Intel bracket.




❻ Plug the power cable into "CPU-FAN" interface.


For **AMD** Platform




❶ Install CPU, then install the buckle on AMD motherboard. (Any questions please contact the motherboard vendor)



❷ Apply the heat-conducting paste evenly on the CPU.



❸ Fasten the hook on both sides of the radiator to the AMD bracket.



❹ Plug the power cable into "CPU-FAN" interface.

From Mars Gaming team: we want to thank you for the purchase of this product!

We try to improve everyday to offer the best service and the best quality on our peripherals. Thank you for your trust!

ARE YOU HAPPY WITH YOUR PURCHASE?

YES



Rate us in your marketplace and share your experience in your social media



@MarsGaming_ marsgamin
MarsGamingOfficial

NO



Please contact our technical support service by sending an e-mail to



support@marsgaming.eu